

Announcements

- Reading
 - Chapter 2 (2.1 & 2.2)
- Project #4 will be out next week
- Homework #1
 - Due 11/6/01
 - Chapter 6: 4, 12, 24, 37

Performance Issues

- **Broadcast storms**
 - response to a broadcast packet sent by many hosts
 - caused by:
 - bad parameter resulting in an error message
 - asking a question everyone has the answer to
- **Reboot storms**
 - RARP queries
 - file servers responding to page requests
- **Delay-bandwidth product**
 - need to buffer at least as many bytes as can be “in flight”
- **Jitter**
 - keep standard deviation of packet arrivals low
 - important for continuous media traffic

How to Measure Performance

- **Ensure sample size is large**
 - repeat experiments for several iterations
- **Make sure samples are representative**
 - consider time of day, location, day of week, etc.
- **Watch for clock resolution/accuracy**
 - don't use two clocks at opposite ends of the network
 - if the clock resolution is poor, aggregate over multiple iterations
- **Know what you are measuring**
 - is a cache going to distort results?
 - is the hardware, OS, device driver, compiler the same?
- **Careful not to extrapolate too far**
 - results generally hold for an operating region, not all values

How to Design in Performance

- CPU Speed is more important than link speed
 - protocol processing time is the critical time for most networks
 - use simple algorithms for your network
- Reduce packet count
 - there is a large per packet cost in most levels
 - big packets amortize this overhead over more bytes
- Minimize Context Switches
 - user/kernel boundary crossings are expensive
 - require many cache misses, pipeline stalls, etc.
 - send large units of data
- Minimize Copying
 - each copy is extra time
 - memory operations are often 10 times slower than other insns

How To Design In Performance (cont.)

- Bandwidth is growing, but latency isn't shrinking as fast
 - fundamental limits of how many rounds trips are possible
 - need to design to transfer large requests
- Congestion Avoidance beats Recovery
 - getting the network out of a bad state will take time
 - better to prevent getting it there in the first place
- Avoid Timeouts
 - use NACKs to get info back
 - use long values for timeouts
 - timeouts result in:
 - interrupts (slow for the processor)
 - re-transmission (slow for the link)
- Make The Common Case Run Fast
 - data transmission is more common than connect

Sending Information

- data is sent by varying a value over time
 - can model this as a single valued function $f(t)$
 - the physical property that is changed could be
 - current
 - voltage
- goal is to analyze the properties of this function
 - how much energy is required?
 - how does the physical media affect the signal


Fourier Analysis

- Any periodic function $g(t)$ can be represented by
 - a constant term
 - a series (possibly infinite) of sines and cosines
 - a signal has a fundamental frequency $f=1/T$
 - each term is called a harmonic


$$G(t) = \frac{1}{2}c + \sum_{n=1}^{\infty} a_n \sin(2\pi nft) + \sum_{n=1}^{\infty} b_n \cos(2\pi nft)$$

- finite functions can be repeated forever
 - effectively any signal is finite so it has a Fourier transform


How many Harmonics do we need?



(a)




(b)



(c)



(d)



(e)

figure copyright , 1996, Andrew S. Tanenbaum

● Adding Harmonics

- reduce error in regenerated signal
- requires additional bandwidth

Importance of Harmonics

- **Bandwidth limits**
 - physical circuits often only pass up to a cutoff frequency
 - sometimes limit bandwidth (it costs money)
- **Non-Uniform Attenuation**
 - not all frequencies pass equally well
 - 60 Hz is a bad frequency due to electrical circuits
 - try to ensure that the “important” parts get through
 - this is called distortion
 - exactly like bad sound when you turn up the stereo amp

Why baud may not equal bits/sec

- baud is number of changes per second
 - if the signal has 0/1 volts then bits/ baud == 1
 - but if 0,1,2,3,4,5,6, and 7 volts used then 3 bits/ baud
- limit on baud per second over a phone line
 - phone lines are limited to about 3khz
 - so only harmonics less than 3,000 will get sent
 - for 9600Bps the first harmonic is at 1,200
 - only two harmonics will be sent
 - not possible to send past 38.4kBps
 - but Baud is not bit/sec